



Notes:

1. If lining is to be carried over metal embedment, saw cut toe-in termination is still required.
2. On vertical applications, Series 435 will require Series 211-211 Fumed Silica or other approved bulking powder to fill the 1/4" saw cut.

N.T.S.

**TNEMEC PERMA-SHIELD
STANDARD LINING DETAILS**

TERMINATION OF EMBEDDED METALS

NO. PLS-2

REV. 1