



NOTES:

1. PREPARE CRACK OR JOINT USING A CRACK CHASING TOOL OR CHIPPING GUN. FOLLOW THE CRACK MAKING A 1/2" WIDE X 1/2" DEEP "V" CENTERED ON THE CRACK. REMOVE ALL DUST AND DEBRIS.
2. PREPARE CONCRETE SURFACE IN ACCORDANCE WITH THE RESPECTIVE ELASTO-SHIELD PRODUCT DATA SHEET AND APPLICATION GUIDELINES.
3. APPLY SERIES 265 IN A 2-4" WIDE STRIP CENTERED OVER THE JOINT. USE MASKING TAPE TO KEEP BOUNDARY TAPE LINES STRAIGHT AND WITHIN STRIP WIDTH. REMOVE TAPE WHILE SERIES 265 IS WET. ALLOW SERIES 265 TO CURE MINIMUM 4 HOURS.
4. APPLY SPECIFIED ELASTO-SHIELD LINING SYSTEM IN ACCORDANCE WITH THE PRODUCT DATA SHEET AND APPLICATION GUIDE.

TNEMEC ELASTO-SHIELD STANDARD LINING DETAILS

**CONSTRUCTION JOINT OR CRACK
FOR IMMERSION SERVICES**

NO. ELS-6

REV. 0