



Notes:

1. Remove deteriorated or loose concrete surrounding steel reinforcing bar (rebar), including 3/4" around entire circumference of rebar, in accordance with ICRI guidelines No.310.1R.
2. Abrasive blast to a SSPC-SP10/NACE No. 2 or power tool clean to a SSPC-SP11.
3. Apply 1 coat of Series 1 (or similar). Avoid spillage or application onto the parent concrete.
4. Build a substrate flush to original concrete plane.

N.T.S.

**TNEMEC PERMA-SHIELD
STANDARD LINING DETAILS**

EXPOSED REBAR REPAIR

NO. PLS-8

REV.1